



# AU25748T

## 100 Litre Toxic Substance Storage Cabinet



### AU25748T

Toxic Substance Storage Cabinet  
Complies with AS/NZ 4452  
100 Litre Capacity

External Size: 800mmH x 920mmW x 565mmD  
Internal Size: 560mmH x 830mmW x 480mmD

Supplied with two metal shelves as standard.

Extra shelves may be added.

Product Codes:

PBA Code - 25937UP Upper Shelf  
PBA Code - AU25937 Lower Shelf

FM Approved  
(Factory Mutual Insurance Endorsement)

All Justrite Storage Cabinets are manufactured to comply fully with the relevant Australian Standards.

Powder Coat paint finish provides a superior no drip, high gloss finish which minimises the effects of corrosion and humidity. The durable finish can withstand the abrasive type abuse as other types of finishes.

Locking Mechanism, the three point locking with fail safe closing mechanism. The locking bars are specially developed to avoid bending and distortion providing a distinct locking effect. The locking also has an option to padlock the cabinet as well.

All cabinets are fitted with self closing sequential closing doors allowing the left door to close followed by the right door. This then provides a seal around the doors.

Full length door piano hinge provides a durable sealed barrier to cabinet contents.  
Adjustable levelling feet at all four corners.

Shelving design permits the ventilation throughout the cabinet and troughs in each shelf collect spills and direct these away from contaminating products stored on the lower shelves.  
Shelves are adjustable incremental 76mm.

Each cabinet is provided standard with a 150mm deep fully sealed sump to contain spills or leaks within the cabinet. An additional shelf is included in our pricing to fit above the sump and utilise this as additional storage area.

Self closing mechanism is housed in the roof of the cabinet. This provides additional area within the cabinet for storage and avoids damage and alignment disorder. Cabinet closure rates are easily adjusted by removal of the four self tapping screws.

Dual 50mm NPS vents are provided with built in flash arresters. Where applicable hazardous vapours may be piped away.

Thermal Fusible Door Links for holding doors open while loading and unloading. This link separates at a temperature of 72 degrees to allow doors to close.

Double wall thermal barrier. 1.2mm steel thickness with 40mm air wall spacing.

After sales service and training available. It is our pleasure to provide a presentation after installation of the Justrite cabinets on the proper use and functions of each cabinet.

Delivery, most cabinets are available ex stock to meet your requirements.

10 years manufacturing warranty

# AU25748T

## Toxic Substance Storage Cabinet

### 100 Litre

